



CONTOUR CHECK

Real-time laser profile measurement
for long products



CONTOUR CHECK

The smart way to optimize your rolling process

CONTOUR CHECK offers multiple benefits for the inline measurement of long products. Whether you're dealing with wire, rod, bar, or tubes, our system can measure relevant dimensions and detect changes in shape, rolling defects, and surface defects. Thanks to its advanced capabilities, CONTOUR CHECK can provide warnings when tolerances are exceeded, allowing you to intervene

before significant amount of scrap is produced. Moreover, the system can substantially reduce start-up times after product changes by measuring from the first moment material comes through. With CONTOUR CHECK's cutting-edge laser technology, you can considerably optimize your operations and improve your product quality.

Content	Page
Integrated solution for your rolling mill	4
Real-time process monitoring	5
CONTOUR CHECK WIRE	6
CONTOUR CHECK BAR & TUBE	10
CONTOUR CHECK ROUND & EDGE	14
CONTOUR CHECK SHAPE	18
Model overview	24
Measuring methods	25
References	26


Fast, reliable, precise

Integrated solution

for your rolling mill

CONTOUR CHECK provides all the information needed for fast and precise adjustment of rolling lines. Depending on the model, it can measure rounds, rebar, flats, squares, hexagons, or even octagons. The patented technology allows precise identification of roller misalignment, two- and one-sided over- and underfilling of the groove pass, even at a high vibration and rotatory movement of the rolled material.

Off-size conditions are immediately displayed and allow corrections during the runtime of a billet. Elimination of sample cutting and quantity reduction of billet samples reduce the ramp-up time after a size or product change. Precise determination of off-size lengths at head and tail allows crop optimization, further increasing the yield.



LAP provides several measurement solutions fitting to ambient conditions of certain line positions.

Check, detect, improve

Real-time process monitoring

Your customers' satisfaction depends on the quality of the products you provide. The quality depends on your control of the production process. For control, you need precise, detailed, reliable information delivered in real time.

CONTOUR CHECK provides this data for process control and documentation.

- Check dimensions and show trends
- Detect rolling defects and offer solutions
- Detect surface defects
- Connect several CONTOUR CHECK systems for a comprehensive process analysis

Benefits



Monitoring

CONTOUR CHECK shows you what happens in your production. You can see trends, implement corrective action and check the impact before exceeding a limit. If sudden errors occur, they are documented for later handling.



Quality

Deliver optimum quality and stand out from your competitors. Quality equals saving money, as you increase efficiency and yield, and you reduce scrap as well as customer complaints.



Documentation

All data is recorded and saved to a database. You can access to parameters and measure values for all jobs, batches, and single products.



Analysis

Use filed data for precise analysis of production parameters. Save money by using the optimum parameter set. Detect weaknesses before they have visible impact on your production.

CONTOUR CHECK
WIRE 45-1



CONTOUR CHECK
WIRE 45-2/3 C-Frame



CONTOUR CHECK WIRE

CONTOUR CHECK WIRE is a laser gauge profile measurement system that quickly and accurately quantifies the diameter for small round cross sections. In the version with 1 axis, it can precisely measure wires. The CONTOUR CHECK WIRE with 2 or 3 axes in an O-frame is even suitable for hot bars and reinforced bars.

The compact industrial design and the use of SMART CORE BASIC software optimized for monitoring rolling processes makes the WIRE gauge reliable and easy to integrate into production control systems. It is cost-effective, fast, flexible and increases accuracy, leading to quick returns on investment.

- Dimensional measurement of wires and reinforced bars
- Measurement range of 45 mm
- Three economic housing types
- 1 axis for diameter measurement
- 2 or 3 axes for measuring the diameter and ovality
- C-shape frame for easy installation
- O-Frame shape for temperature resistance in terms of accuracy
- Dirt, humidity, and thermal protection with permanent airflow (air purge)


CONTOUR CHECK
WIRE 45-2/3 O-Frame




Products



Wire



Bar



Rebar

Benefits



Cost-effective;
Quick pay off



Quick and easy
integration




For cold, warm, and hot
applications (max 1200°C)





Small, mobile frame

CONTOUR CHECK WIRE

Technical data and software SMART CORE BASIC



Standard view for a 3-axis round measurement with current measurement values and statistics by axis (top), line charts for diameter and ovality (middle), nominal and limit values (bottom left), and function buttons (bottom right)



CONTOUR CHECK WIRE 45-1

CONTOUR CHECK WIRE 45-2/3 C-Frame

CONTOUR CHECK WIRE 45-2/3 O-Frame

Measuring range [mm]	45	45	45
Accuracy (trueness) [mm]	±0,015	±0,015	±0,015
Repeatability (precision) [mm]	0,004	0,004	0,004
Material temperature [°C]	≤40	≤300	≤1200
Number of axes [pc]	1	2, 3	2, 3
Frame type	C-Shape	C-Shape	O-Shape
Frame width [mm]	190	620	650
Frame height [mm]	630	718	718
Frame depth [mm]	82	78	78
Passline height [mm]	315	358	358
Frame weight [kg]	13	53	56
Positioning system (optional)	No	Yes	Yes

Blower

No



Air cooling unit
(optional, dimensioning depends on ambient conditions)

No




Pyrometer (optional)

No

No

No

Standard



Measuring frame with sensors ■ Control panel with Ethernet gateway
Software license SMART CORE BASIC ■ Cable between measuring frame and control panel
Sensor parameter set ■ Blower ■ Air temperature sensor ■ Air flow monitor

Optional



Masterpiece and holder ■ Cooling unit for higher inlet air temperature
PC-Set ■ Software add-on for rebar measurement
Level 2 connection ■ Commissioning

CE



General

Round

Rebar

Flat

Square

Hexagonal

Octagonal

Software

Data

CONTOUR CHECK BAR & TUBE



CONTOUR CHECK BAR & TUBE

CONTOUR CHECK BAR & TUBE is a non-contact measurement system with laser scanning sensors that measure the diameter and ovality of mid-size round material. The profile measurement system provides all the information needed for fast and precise adjustment of rolling lines and can measure rounds and rebars. Eliminating sample cuttings reduces the ramp-up time after a size or product change, and precise determination of off-size lengths at head and tail allows crop optimization, further increasing mill yield.

The CONTOUR CHECK BAR & TUBE is available with measuring ranges of 90 mm, 120 mm, 150 mm and can be exposed to material temperatures of up to 200 °C.

- Dimensional measurement of bars
- Measures diameter and ovality
- Measurement range of 90 mm / 120 mm / 150 mm
- Maximum material temperature 200 °C
- 2 or 4 axes
- Dirt and humidity protection with permanent airflow (air purge)

Products



Wire



Bar



Rebar



Tube

Benefits



Specialized in bar and tube lines with a max. measurement range of 150 mm



Quick and easy installation in existing production lines




Cost-effective measurement solution for products up to 200 °C










Documented quality

CONTOUR CHECK BAR & TUBE

Technical data and software SMART CORE ADVANCED



Standard view for a 6-axis round measurement with presets (top left), cross section (top middle), current measurement values and statistics by axis (top right), line charts for diameter and ovality (bottom)

			
	CONTOUR CHECK BAR & TUBE 90	CONTOUR CHECK BAR & TUBE 120	CONTOUR CHECK BAR & TUBE 150
Measuring range [mm]	90	120	150
Accuracy (trueness) [mm]	±0,020	±0,025	±0,030
Repeatability (precision) [mm]	0,0045	0,005	0,008
Number of axes [pc]	2, 4	2, 4	2, 4
Frame width [mm]	1100	1580	1580
Frame height [mm]	1115	1595	1595
Frame depth [mm]	155	155	155
Passline height [mm]	565	805	805
Frame weight [kg]	200	370	390
Positioning system (optional)	Yes	Yes	Yes
Blower			
Air cooling unit (optional, dimensioning depends on ambient conditions)			
Pyrometer (optional)	No	No	No
Standard	 <p>Measuring frame with sensors ■ Control panel with Ethernet gateway Server PC with evaluation SW and data archive Software license for 2P round ■ Cable set ■ Calibration set Blower ■ Set of hoses</p>		
Optional	 <p>Software add-on for rebar measurement ■ Level 2 connection Positioning system ■ Cooling unit ■ Big LED display Industrial PC-set ■ iba interface</p>		



General

Round

Rebar

Flat

Square

Hexagonal

Octagonal


Software

Data

CONTOUR CHECK ROUND



CONTOUR CHECK EDGE



CONTOUR CHECK ROUND & EDGE

CONTOUR CHECK ROUND is the standard solution for dimensional measurement of round profiles and rebars up to 1200 °C. The versions with 3 or 6 axes can precisely measure round material produced by Y rolling stands.

CONTOUR CHECK EDGE uses a set of sensors on an oscillating baseplate. In this way, square, flat, or hexagonal profiles can also be handled. The baseplate can also move to a certain angle position to measure the suitable groove pass related dimensions of round material statically. Both systems use METIS laser micrometers in standard or "big diameter" configurations.

LAP provides the SMART CORE ADVANCED software to complete the solution for CONTOUR CHECK ROUND & EDGE systems.



Standard layout for one axis



"Big diameter" layout for one axis

- Slim housing, can be moved in and out of the production line on a rail
- Mechanically stress-free base plate carries sensors separated from the housing
- Thermal protection by airflow and air cooling

Products



Wire



Square




Bar



Flat



Rebar



Hexagonal



Tube

Benefits



Stable data capturing & processing for products up to 1200 °C



Supervision:
show deviations and errors occurring during the production process



Increased
product quality



Assures minimal product
changeover times

CONTOUR CHECK ROUND & EDGE

Technical data



CONTOUR CHECK ROUND 45

	Profiles	Visible rolling defects
 2 Axes ROUND		
 3 Axes ROUND		
 3 Axes EDGE		
 4 Axes ROUND		
 4 Axes EDGE		
 6 Axes ROUND		
 6 Axes EDGE		

Measuring range [mm] 45

Accuracy (trueness) [mm] $\pm 0,015$

Repeatability (precision) [mm] 0,004

Number of axes [pc] 2, 3, 4, 6

Frame width [mm] 860

Frame height [mm] 940

Frame depth [mm] 81

Passline height [mm] 450


Frame weight [kg] 125

Positioning system (optional) Yes

Blower









Air cooling unit (optional, dimensioning depends on ambient conditions)



Pyrometer (optional) Yes

Standard

Optional

			
CONTOUR CHECK ROUND 90	CONTOUR CHECK ROUND 120/150	CONTOUR CHECK ROUND 180/230	CONTOUR CHECK ROUND 500
CONTOUR CHECK EDGE 90	CONTOUR CHECK EDGE 120/150	CONTOUR CHECK EDGE 180/230	CONTOUR CHECK EDGE 500
90	120/150	180/230	500
±0,020	±0,025/±0,030	±0,035/±0,045	±0,090
0,0045	0,005/0,008	0,010/0,012	0,025
2, 3, 4, 6	2, 3, 4, 6	2, 3, 4, 6	2, 3, 4
1240	1720	2250	2550
1170	1685	2215	2515
253	253	253	253
570	835	1100	1250
580	930	1500	1900
Yes	Yes	Yes	Yes
			
			
Yes	Yes	Yes	Yes
			
Server PC with evaluation SW and data archive & control cabinet Measuring rate: 800 Hz ■ Temperature and air flow monitoring in frame Software license for 2P round ■ Cable set ■ Calibration set ■ Blower ■ Set of hoses			
   			
Different options for control cabinet, control panel, and visualization devices ■ Software add-ons for different profiles Database extension ■ Cooling unit ■ Different positioning systems ■ Industrial PC-set Level 2 interface ■ iba interface ■ Multi-client application ■ Speed monitoring Software add-on for 3-roll technology ■ Software add-on for rebar measurement Different integrated pyrometer sets ■ Uninterruptible power supply ■ Big LED display or big monitor Air conditioning unit for cabinet ■ Measuring rate 1600 Hz or 2000 Hz			



General

Round

Rebar

Flat


Square

Hexagonal

Octagonal

Software

Data



CONTOUR CHECK SHAPE


CONTOUR CHECK SHAPE

CONTOUR CHECK SHAPE is a laser-based measurement system for long products. The purpose of CONTOUR CHECK SHAPE is to control all dimensions and detect rolling defects during the production process of long products. The system can be applied for inline measurement of long products before and after a rolling stand and for both hot and cold material. The revised rebar software add-on offers even more measurement details for ribbed steel. The cameras are protected by 4 measures: heat shield, air purging, airflow around the sensors, and water-cooling. The laser lines are blue, violet, or green for optimal visibility on glowing surfaces.





The rugged, robust design of CONTOUR CHECK SHAPE is based on more than 30 years of experience in supplying systems for rolling mills.

- Standardized gauge with no moving parts
- Detection of geometrical deviations of nominal profile, rolling, and surface defects
- Temperature stabilized setup
- Supporting various profile types
- Closed thermal design for extreme conditions
- Standardized setup for measuring ranges from 50 mm to 500 mm, bigger measuring ranges upon request
- High accuracy and simple calibration
- Intuitive software for visualization and documentation

Products




Benefits

-  100 % process monitoring
-  Applicable to multiple contours with a max. temperature of 1200 °C
-  Scrap reduction/instant recognition of anomalies
-  Automatic detection of important rolling and surface defects

Surface defect detection

SMART CORE PRO software provides users of CONTOUR CHECK SHAPE systems with intelligently configured visualization of geometrical data that can be applied directly in the process line and in the data structures of an Industry 4.0 production environment. SMART CORE PRO shows profile deviations and surface defects at a glance.



CONTOUR CHECK SHAPE

Technical data



CONTOUR CHECK SHAPE 50

Measuring range [mm]	50
Accuracy (trueness) [mm]	±0,015
Repeatability (precision) [mm]	0,003
Number of cameras [pc]	4
Frame width [mm]	1270
Frame height [mm]	1280
Frame depth [mm]	370
Passline height [mm]	450
Frame weight [kg]	355
Positioning system (optional)	Yes

Blower



Air and water cooling unit
(dimensioning depends on ambient conditions)

Pyrometer (optional)

Yes

Standard

Optional

Detectable rolling defects

CONTOUR CHECK SHAPE 100

100

±0,025

0,006

4

1270

1480

470

540

435

Yes

CONTOUR CHECK SHAPE 150

150

±0,040

0,009

4

1470

1680

550

640

585

Yes

CONTOUR CHECK SHAPE 250

250

±0,065

0,015

4

1770

2170

640

780

895

Yes

CONTOUR CHECK SHAPE 500

500

±0,100

0,030

4

2400

2590

745

890

1370

Yes




Yes

Yes

Yes




Yes



Control cabinet with HMI ■ Control panel including controller ■ Several software licenses

Several temperature and air flow sensors ■ Measuring rate up to 2000Hz

Cable set ■ Calibration set ■ Blower ■ Set of hoses ■ Water conditioning unit ■ Fluid connection set



Multi-client application ■ Different integrated pyrometer sets ■ Speed monitoring ■ Air-condition for cabinet

Software add-on for 3-roll technology ■ Software add-on for rebar measurement

Uninterruptable power supply ■ Big LED display or big monitor ■ iba connection ■ Level-2 interface

Software add-ons for different profiles ■ Software add-on for surface defect detection

Different positioning systems ■ Industrial PC-set ■ Software add-ons for different profiles



General

Round

Rebar

Flat

Square

Hexagonal

Octagonal

Software

Data


CONTOUR CHECK SHAPE

SMART CORE PRO

software


The functions and display of SMART CORE PRO are optimized for monitoring rolling processes. The GUI offers the possibility to show line graphs, cross section, numerical values, visualization of rolling defects, tables, and much more. Besides

standard screens, customers can modify or create new screens to their needs. The software offers the unique functionality to automatically rotate the wire or rod to mill orientation to directly measure the real rolling defects.




First screen:

Round profile with under-filling and a big defect, produced by a H/V stand



Second screen:

Round profile with under-filling and a big defect, produced by a H/V stand



Rebar: i.e. core dimensions, rib height, diameter on certain positions, and mass per length are measured

Industry 4.0 ready

- SMART CORE PRO finds defects on the surface over the complete shape
- Profile cross section, numerical values, production history, pass/fail information and production details
- Visualization can be configured to specific user requirements
- Database for long-term storage of relevant data
- Multi-client capable even on Windows tablets
- Interfaces to process data acquisition and analysis systems such as iba network connectivity
- Up to 4 systems can be connected to and evaluated by one server
- Connection via level-2 interface for data exchange with the control system (as well as all other measuring frames from LAP)

CONTOUR CHECK

Model overview



**CONTOUR CHECK
WIRE**

**CONTOUR CHECK
BAR & TUBE**

**CONTOUR CHECK
ROUND**

**CONTOUR CHECK
EDGE**

Round



Diameter, ovality



Diameter, ovality



Diameter, ovality



Diameter, ovality

Square



Height, width,
diagonal length

Flat



Height, width,
diagonal length

Hexagonal



Distance between
corners,
width across flats

Octagonal

Rebar

Yes

Yes

Yes

**Material
temperature**

Up to 1200 °C

200 °C

1200 °C

**Rolling
defects**

Not detected

Detection of irregularities,
interpretation required

Detection of irregularities, interpretation required

**Defects on
surface**

Not detected

Not detected

Not detected

**Measurement
scope**

Outer dimension
(Shadowing)

Outer dimension
(Shadowing)

Outer dimension
(Shadowing)



CONTOUR CHECK SHAPE

● Diameter, ovality, groove pass related diameters

■ Height, width, side length, diagonal length, corner radius, corner angle, convexity and concavity of sides, parallelism of sides

■ Height, width, side length, diagonal length, corner radius, corner angle, convexity and concavity of sides, parallelism of sides

⬡ Side relations, side length, distance between corners, width across flats, corner radius, corner angle, convexity and concavity of sides, parallelism of sides

⬢ Side relations, side length, distance between corners, width across flats, corner radius, corner angle, convexity and concavity of sides, parallelism of sides

Yes


1200 °C

Detection and identification

Detected within specified limits


Surface profile
(Laser Light Section)

Measuring methods



Shadowing method

One sensor consists of an emitter and a receiver in separate housings. In the emitter, a laser beam hits a rotating polygon mirror. The deflected beam is converted into a beam that periodically runs through the measuring area, building a virtual light band. The parallel moving beam in the receiver is focused on a light-sensitive diode. Any object within the measuring field partially shadows the receiver. The time interval of shadowing precisely determines the dimension of the object. LAP uses METIS laser micrometers of our own design and production.




Laser light section method

The sensor contains a line laser, a high-dynamic machine vision camera, and electronics for processing the camera signals. The laser projects a straight line perpendicular to the surface to be measured. The camera is fixed at a certain angle to the laser line. Any deformation of the surface causes a deformation of the laser line from the camera's angle of view. Using the basic calibration as a reference, the sensor calculates the dimensional values. LAP designs and manufactures laser light section sensors using its own laser technology and high-end industry cameras that best fit the customer's requirements.

References

LAP's laser measurement systems help leading steel manufacturers worldwide to optimize their production processes and improve quality. Our systems enable the measurement of crucial geometrical values, such as height, width, length, diameter, and ovality of steel products, whether they are intended for hot or cold applications. Here you will find an excerpt from the reference list of our worldwide customers focusing on the main regions.



500 +
Systems in use

Europe

- CONTOUR CHECK SHAPE 50 for measuring diameter and ovality as well as detecting surface defects of wire in a wire rod mill
- CONTOUR CHECK SHAPE 250+50 for measuring outer dimensions, corner radius, and specific welding parameters, as well as detecting surface defects of square and flat profiles in a tube mill
- CONTOUR CHECK ROUND 120-4 for measuring the diameter and ovality of bar, rod, and rebar in a bar mill

USA and Canada

- CONTOUR CHECK ROUND 90-6 for measuring the diameter and ovality of wire in a wire rod mill
- CONTOUR CHECK SHAPE 50 for measuring groove pass-related diameters of wire in a wire rod mill
- CONTOUR CHECK ROUND 45-6 for measuring the diameter, ovality, and cross-section area of wire in a wire rod mill

China

- CONTOUR CHECK SHAPE 150+60 for measuring cross-sectional dimensions of round and special flat profiles in a bar mill
- CONTOUR CHECK SHAPE 100 for measuring the diameter and ovality, as well as detecting surface defects of bar and rod in a bar mill
- CONTOUR CHECK ROUND 90-4 for measuring the diameter, ovality, and cross-sectional area of wire in a wire rod mill

Japan

- CONTOUR CHECK ROUND 150-4 for measuring the diameter and ovality of bar, rod, and rebar in a Y-stand bar mill
- CONTOUR CHECK SHAPE 500 for measuring the cross-section of round and flat profiles
- CONTOUR CHECK ROUND 150-6 for measuring the diameter and ovality of round profiles in a bar mill

South Korea


- CONTOUR CHECK EDGE 90-4 for measuring the diameter and ovality of wire in a wire rod mill

About us

LAP is one of the world's leading suppliers of systems that increase quality and efficiency through laser projection, laser measurement, and other processes. Every year, LAP supplies 15,000 units to customers in industries as diverse as radiation therapy, steel production, and composite processing. LAP employs 300 people at locations in Europe, America, and Asia.



90+
Partners



300
Employees



8
Locations



Quality

We work to uniform standards and with certified processes. For us, "Made in Germany" means the highest precision in manufacturing and quality inspection of each device. For our customers, this means planning and process certainty.

All our worldwide locations use a quality management system according to EN ISO 13485 or EN ISO 9001. Our products have all the necessary approvals and registrations almost everywhere in the world.



Service

We ensure the maximum availability of your equipment so you can concentrate on your core process. Wherever you need us, our certified service technicians are quickly on site in any time zone. We support you from installation and commissioning, through user training, up to maintenance, repair, or unit replacement.

Our efficient logistics ensure the fast availability of spare parts worldwide. For technical questions and support, our helpdesk is at your disposal by telephone, via e-mail, or remote diagnosis.



**made
in
Germany**

Contact us!
info@lap-laser.com

Contact us!

P +49 4131 95 11-95

E info@lap-laser.com

in LAP Laser

▶ [laplaser](#)

LAP Measurement Technology GmbH

Zeppelinstr. 23

21337 Lüneburg

Germany

LAP GmbH Laser Applikationen, Germany / LAP Measurement Technology GmbH, Germany / LAP Sued GmbH, Germany / LAP FRANCE SAS, France / LAP GmbH Laser Applikationen c/o representative office DMAN, Russian Federation / LAP Laser Applications Asia Pacific Pte. Ltd., Singapore / LAP Laser Applications China Co. Ltd., China / LAP of America Laser Applications, L.L.C., USA / LifeLine Software, Inc., USA
Our worldwide partners: Argentina / Australia / Brazil / Bulgaria / Canada / Chile / Colombia / Croatia / Czech Republic / Dominican Republic / Egypt / Finland / Greece / Hungary / India / Indonesia / Italy / Japan / Jordan / Kuwait / Latvia / Lebanon / Lithuania / Malaysia / Mali / Malta / Mexico / Netherlands / Norway / Oman / Philippines / Poland / Portugal / Qatar / Romania / Saudi Arabia / Slovakia / Slovenia / South Africa / South Korea / Spain / Sweden / Switzerland / Taiwan, China / Thailand / Turkey / United Arab Emirates / United Kingdom / Venezuela / Vietnam / Zambia

www.lap-laser.com/contour-check

LAP is a registered trademark of the LAP Group in several countries worldwide including the USA and EU. Designations of other companies and products are used for identification purposes only (e.g. to inform about the compatibility). These names can be trademarks or registered trademarks which belong to their respective owners. The use of any of these trademarks by third parties may infringe the rights of the respective owner.